


Rewireable Continental European Plug 88010802

Assembly Instruction

Disconnect power before wiring.

Keep removed piece parts at a safe place to have them ready for reassembling.

1. Loosen cover screws and remove cover.
2. Loosen cable clamp screws and remove cable clamp.
3. Strip the outer jacket as shown in diagram. Make sure not to damage insulation conductors.
4. Strip each insulation conductors as shown in diagram.
5. Loosen contact screws but do not remove screws.
6. Connect green/yellow (ground) wire to center clamp marked with ground symbol .
7. Connect blue wire to clamp marked "N" (neutral).
8. Connect brown wire to clamp marked "L" (line).
9. Tighten all contact screws with a torque of 0.5 Nm (4.5inlbs).
10. Assemble cable clamp over cut-off end of outer jacket of the cord and tighten cable clamp screws.
11. Assemble cover and tighten screw.

Warning: Failure to wire as instructed may cause personal injury or damage to device or equipment. To be installed or checked by a qualified person only.

Strip lengths	
A Insulation	B Outer Jacket
7-8mm	28mm
Applicable cable size and type.	
0.75mm ² - 1.5mm ²	H05

Line: Brown

Ground: Yellow/Green

Neutral: Blue

