



**Note 1: Recommended diameter for thru-hole (screw/nut combination) hardware mounting method. Other methods will require holes with different dimensions and parameters.**

<small>THIS DOCUMENT AND ITS CONTENTS ARE THE PROPRIETARY CONFIDENTIAL PROPERTY OF INTERPOWER CORPORATION. NO USE OR COPIES MAY BE MADE WITHOUT WRITTEN PERMISSION FROM INTERPOWER CORPORATION.</small>				<b>DIMENSIONS IN MILLIMETERS</b>		<b>TITLE Swiss Panel Mount Socket</b>	
				<b>DRAFT BY:</b> JPC	<b>DATE:</b> 11-7-2006	<b>PART NUMBER:</b> 88052040	
				<b>DRAFTING APPROVAL:</b> JPC	<b>DATE:</b> 11-7-2006		
<b>A</b>	Added dimension information to cutout screw holes and Note 1.	3/23/12	DDF	<b>MATERIAL:</b>		DO NOT SCALE	<b>INTERPOWER CORPORATION</b>
<b>REV</b>	<b>CHANGE DESCRIPTION</b>	<b>DATE</b>	<b>INITIALS</b>			SHEET 1 OF 1	