

Wiring Instruction for Part 88040290



- 1) Prepare wires by stripping insulation back 8mm.
- 2) Insert wires into terminals and tighten. Wire terminal locations are indicated in the photo above. Recommended torque value of 0.80Nm (7.0inlb) for initial test wiring. Torque can vary depending on the wire, so it is the end users responsibility to test and settle on a final torque value.

Wiring Instruction 88040290

Rev. 08/15/16

Created by DDF

