



- * Use only cable with cross section 0.75 to 1.50mm² (Max. diameter 8.5mm) type H05VV-F.
- * Prepare wires according to the 'Wire Detail' view at the left. Cable entry hole may also need preparation to accept the larger diameter cables, by trimming and enlarging the hole.
- * Insert wires into appropriate terminal locations as demonstrated in the "Wiring View" drawing in the lower left corner. Then, place cable in between strain relief posts.
- * Replace cover and secure.
- * Plug features additional locking feature that will only function with specially designed mating connector (88040210). Plug can be used in conjunction with other connectors, but locking feature will be non-functional.

THIS DOCUMENT AND ITS CONTENTS ARE THE PROPRIETARY CONFIDENTIAL PROPERTY OF INTERPOWER CORPORATION. NO USE OR COPIES MAY BE MADE WITHOUT WRITTEN PERMISSION FROM INTERPOWER CORPORATION.				DIMENSIONS IN MILLIMETERS		TITLE 10A Brazilian Plug Wiring Instructions	
				DRAFT BY: DDF		DATE: 2/23/11	
A		Introduction of part.		2/23/11		DDF	
REV		CHANGE DESCRIPTION		DATE		INITIALS	
				MATERIAL:		DO NOT SCALE	
						SHEET 1 OF 1	
				INTERPOWER CORPORATION			