



Wiring Instruction: BS 546 Plug 88010231 for use in South Africa,

1. Remove plug back-shell.	
2. Using the values stated in the above diagram, prepare the cable and wires for attachment to the terminals. Ensure conductor insulation is not damaged when removing the outer jacket. When stripping the insulation off the conductors, inspect to ensure that strands are not being broken off. If more than 2 strands are broken, it is recommended to cut back and re-strip either with a lighter setting or lighter touch. Note: manufacturer recommended strip length is 8mm, but can be adjusted to make operation easier.	
3. Loosen terminal screws. Insert the wires into the proper terminal locations (as shown above) and retighten screws. Torque for terminal screws recommended at 4.5inlb (0.5Nm) maximum.	
4. Lays the cable in the cord entry track, between the screw receptacle posts. Be sure the jacket is positioned high enough to be beyond the cord grip bar when it is put back into place.	
5. Slightly compressed cable into the cord retention clip shown in photo.	
6. Refit back-shell and tighten screw using recommended torque of 4.5inlb (0.50Nm) maximum. Make sure front and back halves of the plug is fit snugly together. Cord may be tested when assembly is complete.	